



 <p>Security alarm host direction for use</p>	<p><b>Product description</b> Security alarm system is a brand new self-powered intelligent set that provides security protection, elder care, wireless door bell, and all kinds of smart control. It sup</p>  <p>Transmitter      Receiver</p> <p><b>Parameters</b> Product Model: QME Sound Volume: 4 levels adjustable Ringtones: 38 Power Supply of Transmitter: Self-powered Power Supply of Receiver: AC 100-240V 50/60Hz Temperature Range: -20°C ~ 55°C Modulation Method: ASK Working Frequency: RF 433MHz Transmission Distance: 100m(outdoors), 30m(indoors) Plug Type: European Storage Capacity: Up to 10 transmitter can be paired with the receiver</p>	<p><b>Instruction</b> 1.Plug the main alarm panel direct into the AC power socket indoors, when it is connected with power it will enter to the programming status. The products is for indoor use, avoid high temperature, high humidity, dustiness and strong electromagnetic interference</p>  <p>Use the double-sided tape included in the package to attach the doorbell transmitter to the outside of the door where you want to install it. (Please do not stick it on the metal security door, so as not to affect the signal transmission)</p> 	<p><b>Key Function</b></p>  <ol style="list-style-type: none"> <li>① Volume key: Press this key and the volume will switch between levels 1-4.</li> <li>② Ringtone selection key +: Press this key to cycle through the available ringtones.</li> <li>③ Ringtone selection key -/Pairing button: User for pairing and changing the ringtone to the previous one.</li> </ol> <p><b>Pairing Method</b> Long press on Ringtone selection key -/Pairing button for 3 seconds, when the indicator flashes slowly, press selected switch to get both units paired. Indicator goes off that means pair succeeds. When receiver change ringtone, transmitter will work synchronously.</p>	<p><b>Silent Mode</b> When the volume is lowest, it defaults to silent mode.</p> <p><b>Clear Pairing</b> Hold the Ringtone selection key -/Pairing button for about 12 seconds, the indicator of receiver will flash then goes off, memory is cleared. Repeat the pairing operation if new wireless control is requested.</p> <p><b>Menory</b> When power cut happens, reconnect the power, doorbell will play the last ringtone and same sound volume selected before power cut.</p> <p><b>Rebuilt Default Setting</b> Long press volume key for 3 seconds, loose finger when indicator light becomes constant on, now doorbell plays the default ringtone, sound volume come to default.</p>	<div style="border: 1px solid black; padding: 5px; text-align: center;">Certificate / Inspected</div>
	<p>70.00 mm</p> <p>90.00 mm</p>				